

INDUSTRIAL COMPONENT DATA

2CLA884408A7201 8844.08 NZ NIESSEN NZ shutter switch/push button

Brand: NIESSEN | Manufacturer Part Number: 2CLA884408A7201



Manufacturer	NIESSEN
MPN / Reference	2CLA884408A7201
Catalog number	8844.08 NZ
Category	Control element/cover plate for domestic switching devices
Minimum order	5 Pcs
Document ID	EO-346E23E640
Generated	2026-08-01

Product Overview

NZ shutter switch/push button

STRUCTURED PRODUCT DATA

Technical Specifications

No structured technical attributes are currently available. Submit an RFQ for technical review.

Classification & Catalog Path

Catalog path **NIESSEN > Industrial**

REQUEST PRICE, AVAILABILITY & TECHNICAL REVIEW

Send NIESSEN / 2CLA884408A7201 with the required quantity to info@electricaonline.com or use electricaonline.com/request-quote.**GLOBAL OFFICES**

Germany: Lise-Meitner-Straße 13, 89081 Ulm | USA: 16225 Park Ten Pl #500, Houston, TX 77084 | UAE: HDS Business Centre Tower, Cluster M, 33rd Floor, JLT, Dubai

Catalog-generated document. Product names, marks and specifications belong to their respective owners. Verify safety-critical, compatibility and certification requirements against the manufacturer documentation before purchase or installation.